


## ● Connection Diagrams


The figure below is a connection diagram for a configuration based on a single-phase 100–120 V supply voltage, with the sink/source selector switch set to the sink side.




- \*1 The grounding method will vary depending on the length of the connection cable.  
When the connection cable is 7 m (23 ft.) or shorter: Connect the protective grounding terminal on the connection cable to the protective grounding terminal on the driver.  
When the connection cable is 10 m (32.8 ft.) or longer: Connect the protective grounding terminal of the motor directly to the grounding point.
- \*2 The main circuit is insulated to prevent electrical shock resulting from accidental contact by a hand, etc.
- \*3 The signal-cable connection terminals and the signal cable including the shielded cable comprise an ELV circuit, which is insulated from dangerous voltages only by means of basic insulation. Therefore, connect the shielded cable to the GND point specified in the connection diagram, instead of connecting it to a protective grounding terminal.
- \*4 The I/O-signal connection terminals comprise a SELV circuit, which is insulated from dangerous voltages by means of double insulation or reinforced insulation.

## ◆ Applicable Crimp Terminals

- Power Supply Connection Terminal (M3.5): Round shape terminal with insulator




- Protective Earth Terminal (M4): Round shape terminal with insulator



## • I/O Terminals


Use the terminals specified below for connection using crimp terminals. Please note that the applicable crimp terminal will vary depending on the size of the wire. The following terminals can be used with wires of AWG26 to 22.

- [Manufacturer: Phoenix Contact]
- AI 0.25-6 Applicable cable size : AWG26~24 (0.14~0.2 mm<sup>2</sup>)
- AI 0.34-6 Applicable cable size : AWG22 (0.35 mm<sup>2</sup>)




## ● Timing Chart

### ◆ 2-wire Mode



- The CW input signal, CCW input signal and DEC-STOP signal can be used to control all motor operations, such as run, stop, direction switching, deceleration stop and instantaneous stop.
- Switching the CW signal ON will cause the motor to turn clockwise as viewed from the motor shaft, while switching the CCW signal ON will cause the motor to turn counterclockwise. Switching each signal OFF will stop the motor. If both the CW signal and CCW signal are turned ON at the same time, the motor will stop instantaneously. The motor will start at the rise time corresponding to the acceleration time (ACC) set on the digital operator.
- Switching the DEC-STOP signal ON will cause the motor to decelerate at the deceleration time (DEC) set on the digital operator until it eventually stops. Switching the DEC-STOP signal OFF will cause the motor to stop instantaneously.

### ◆ 3-wire Method



- The START/STOP signal, RUN/BRAKE signal and CW/CCW signal can be used to control all motor operations, such as run/stop, instantaneous stop and direction switching.
- Switching both the START/STOP signal and RUN/BRAKE signal ON at the same time will start the motor. At this time, switching the CW/CCW signal ON will cause the motor to turn clockwise as viewed from the motor shaft, while switching the signal OFF will cause the motor to turn counterclockwise. The motor will start at the rise time corresponding to the acceleration time (ACC) set on the digital operator.
- Switching the RUN/BRAKE signal OFF while the START/STOP signal is ON will cause the motor to stop instantaneously. Switching the START/STOP signal OFF while the RUN/BRAKE signal is ON will cause the motor to decelerate at the deceleration time (DEC) set on the digital operator until it eventually stops.


## I/O Signal Circuits

The input signal circuit can be switched between the sink mode and source mode using the sink/source selector switch on the driver. The factory setting is the sink mode.


### ◇ Input Circuit

Common to the CW (START/STOP), CCW (RUN/BRAKE), DEC-STOP (CW/CCW), EXT-ERROR, ALARM-RESET and operation-data selection inputs.

#### ● Sink Input




#### ● Source Input



### ◇ Output Circuit

Common to the SPEED-OUT, ALARM-OUT1 and ALARM-OUT2 outputs.


#### ● Sink Output



Y0: SPEED-OUT output\*  
Y1: ALARM-OUT1 output  
Y2: ALARM-OUT2 output

\* Supply a current of 5 mA or more to the SPEED-OUT output.

#### ● Source Output



Y0: SPEED-OUT output\*  
Y1: ALARM-OUT1 output  
Y2: ALARM-OUT2 output


\* Supply a current of 5 mA or more to the SPEED-OUT output.

### ◇ When a Controller with a Built-in Clamp Diode is Used

When you want to use the controller with a built-in clamp diode, pay attention to the sequence of turning on or off the power.

Power ON: Controller ON → Driver ON

Power OFF: Driver OFF → Controller OFF



If the driver power is turned on first when connected as shown above, or the controller power is turned off with the driver power turned on, current will be applied, as indicated by the arrows in the diagram. This may cause the motor to run.

When the power is turned on or off simultaneously, the motor may run temporarily due to differences in power capacity. The controller power must be turned on first, and driver power must be turned off first.


### ◇ SPEED-OUT Output

Pulse signals of 30 pulses (pulse width: 0.2 ms) are output per each revolution of the motor output shaft in synchronization with the motor operation.

By measuring the frequency of SPEED outputs, the motor speed can be calculated.

$$\text{SPEED-OUT Output Frequency (Hz)} = \frac{1}{T}$$

$$\text{Motor Shaft Speed (r/min)} = \frac{\text{SPEED-OUT Output Frequency}}{30} \times 60$$



### ◇ ALARM-OUT1 Output

When any of the driver's protection functions is actuated, the ALARM-OUT1 output will turn OFF and the digital operator will display an alarm code. The motor will decelerate to a stop.

### ◇ ALARM-OUT2 Output

The ALARM-OUT2 output will turn OFF when the driver's overload protection function or overload warning function is actuated. Actuation of any other protection function will not turn this output OFF.


The overload warning function is actuated based on a preset load factor relative to the rated torque. The ALARM-OUT2 output will turn OFF once the set load factor is exceeded.

(A desired load factor can be set at 10% intervals between 50 and 100%.)

Type of Protection Function	ALARM-OUT1 Output	ALARM-OUT2 Output
Normal Operation	ON	ON
Overload Protection Function	OFF	OFF
Other Protection Function	OFF	ON
Overload Warning Function*	ON	OFF

\* A maximum error of approx. 20% may generate when the motor is operated at the rated speed under the rated load.

## Operating Methods




One of the following two operating methods (a and b) can be set by switching between the digital-operator setting mode and external-input signal setting mode.

- Operate the motor using the RUN and STOP keys on the digital operator
- Operate the motor using external input signals


## Speed Setting Methods

One of the following four methods (① to ④) can be used to set speeds:

- Set speeds using the internal potentiometer**  
Set speeds using the potentiometer provided on the driver's front panel.
- Set speeds using the digital operator**  
The digital operator can be used to set speeds in units of 1 r/min. Up to eight speed data can be set.
- Set speeds using an External Potentiometer (sold separately)**  
To set speeds at a location away from the driver, connect an optional external potentiometer as shown below.



External Potentiometer Graduation vs. Speed Characteristics  
(Representative values)




### Note:


The speed in the graph represents the speed of a motor alone. The gear output shaft speed of the combination type is calculated by dividing the graph speed by the gear ratio.

## ④ Set speeds using external DC voltage

Set the external-voltage selection switch on the driver in accordance with the external DC voltage to be supplied. Detach the digital operator and set the switch to either 5 V or 10 V. Thereafter, connect an external DC power supply as shown below. Connect the positive and negative terminals of the power supply correctly.



External DC Voltage vs. Speed Characteristics  
(Representative values)



### Note:


The speed in the graph represents the speed of a motor alone. The gear output shaft speed of the combination type is calculated by dividing the graph speed by the gear ratio.

## Multi-Speed Operation

### ◇ Two-Speed Operation

The speed set by the internal potentiometer and another set by an external potentiometer can be combined for two-speed operation by switching the operation-data selection input M0.


M0 Input	M1 Input	M2 Input	Speed Setting Method
OFF	OFF	OFF	Internal potentiometer
ON	OFF	OFF	External potentiometer



### ◇Eight-Speed Operation

A multi-speed operation using up to eight speeds can be performed by setting desired speeds in operation data No. 1 to 8 and then switching the speed using external input signals.

Operation Data	M0 Input	M1 Input	M2 Input	Speed Setting Method
No. 1	OFF	OFF	OFF	Internal potentiometer/Digital operator
No. 2	ON	OFF	OFF	External potentiometer/Digital operator
No. 3	OFF	ON	OFF	Digital operator
No. 4	ON	ON	OFF	Digital operator
No. 5	OFF	OFF	ON	Digital operator
No. 6	ON	OFF	ON	Digital operator
No. 7	OFF	ON	ON	Digital operator
No. 8	ON	ON	ON	Digital operator



### ●Parallel Operation

Two or more motors can be operated at the same speed using a single external potentiometer or external DC power supply. The diagram below applies to a single-phase power supply specification. For a three-phase power supply specification, change the power-supply line to a three-phase type. Also note that the diagram does not show the motor or operation control part.

### ◇Using an External Potentiometer

As shown in the diagram, use a common power-supply line and a common speed-control line for each driver and set speeds using the external potentiometer VRx.

The resistance of the external potentiometer is determined using the formula below:

Resistance when n numbers of drivers are connected:  $VRx = 20 / n$  (kΩ),  $n / 4$  (W)


Example: When two drivers are connected

$$VRx = 20 / 2 = 10 \text{ (k}\Omega\text{)}, 2 / 4 = 1 / 2 \text{ (W)}$$

Accordingly, the resistance is calculated as 10 kΩ, 1/2 W.

To adjust the speed difference between motors, connect a 1.5 kΩ, 1/4 W resistor to the VM terminal on the first driver, and connect a 5 kΩ, 1/4 W variable resistor (VRn) to the VM terminal on each of the remaining drivers.

Up to five drivers can be operated in parallel using an external potentiometer.



### ◇Using External DC Voltage

As shown in the diagram, use a common power-supply line and a common speed-control line for each driver and connect all drivers to a 5 or 10 VDC power supply.

The power-supply capacity of the external power supply is determined using the formula below:


Power-supply capacity when n numbers of drivers are connected:  $I = 1 \times n$  (mA)

Example: When two drivers are connected

$$I = 1 \times 2 = 2 \text{ (mA)}$$


Accordingly, the power-supply capacity is calculated as 2 mA or more.

To adjust the speed difference between motors, connect a 1.5 kΩ, 1/4 W resistor to the VM terminal on the first driver, and connect a 5 kΩ, 1/4 W variable resistor (VRn) to the VM terminal on each of the remaining drivers.



### ◇Using the Digital Operator

When multiple drivers are connected where the same data are set digitally in each driver, the operations of multiple motors can be controlled via a single set of external input signals using the wiring circuit shown below.



## Installation of the Hollow-Shaft Flat Gearhead

### ● Installing the Load Shaft


- Install the load shaft to the hollow output shaft by aligning the center of the hollow shaft with that of the load shaft.
- The hollow output shaft has a key groove. Machine a matching key groove on the load shaft side and use the supplied key to affix the two shafts across the grooves.
- A recommended tolerance of the load shaft is h7.
- If the motor will receive large impacts due to frequent instantaneous stops or carry a large overhung load, use a stepped load shaft.

#### Notes:

- When installing the load shaft to the hollow output shaft, be careful not to damage the hollow output shaft or bearing.
- To prevent seizure, apply a coat of molybdenum disulfide grease on the exterior surface of the load shaft and interior surface of the hollow output shaft.
- Do not attempt to modify or machine the hollow output shaft. Doing so may damage the bearing and cause the hollow-shaft flat gearhead to break.


### ◇ Stepped Load Shaft

Install a hexagonal socket head bolt over a stopper ring, spacer, flat washer and spring washer, and tighten the bolt to affix the load shaft.



### ◇ Straight Load Shaft

Install a hexagonal socket head bolt over a stopper ring, spacer, flat washer and spring washer, with a spacer also inserted underneath the load shaft, and tighten the bolt to affix the load shaft.



### ● Recommended Load Shaft Installation Dimensions

Unit=mm (inch)


Model	BLF230	BLF460	BLF5120
Inner Diameter of Hollow Shaft (h8)	$\phi 12 \begin{matrix} +0.027 \\ 0 \end{matrix}$ $\left( \phi 0.4724 \begin{matrix} +0.0011 \\ 0 \end{matrix} \right)$	$\phi 15 \begin{matrix} +0.027 \\ 0 \end{matrix}$ $\left( \phi 0.5906 \begin{matrix} +0.0011 \\ 0 \end{matrix} \right)$	$\phi 20 \begin{matrix} +0.033 \\ 0 \end{matrix}$ $\left( \phi 0.7874 \begin{matrix} +0.0013 \\ 0 \end{matrix} \right)$
Recommended Tolerance of Load Shaft (h7)	$\phi 12 \begin{matrix} 0 \\ -0.018 \end{matrix}$ $\left( \phi 0.4724 \begin{matrix} 0 \\ -0.0007 \end{matrix} \right)$	$\phi 15 \begin{matrix} 0 \\ -0.018 \end{matrix}$ $\left( \phi 0.5906 \begin{matrix} 0 \\ -0.0007 \end{matrix} \right)$	$\phi 20 \begin{matrix} 0 \\ -0.021 \end{matrix}$ $\left( \phi 0.7874 \begin{matrix} 0 \\ -0.0008 \end{matrix} \right)$
Nominal Diameter of Stopper Ring	$\phi 12$ ( $\phi 0.47$ ), C-shaped	$\phi 15$ ( $\phi 0.59$ ), C-shaped	$\phi 20$ ( $\phi 0.79$ ), C-shaped
Applicable Bolt	M4	M5	M6
Spacer Thickness*	3 (0.12)	4 (0.16)	5 (0.20)
Outer Diameter of step part $\phi D$	20 (0.79)	25 (0.98)	30 (1.18)

\* Determine the spacer thickness in conformance with the table. If the spacer is thicker than the specified dimension, the bolt will project from the surface and interfere with the safety cover.


### ● Installing the Hollow Shaft

#### ◇ Installing from the Front Face

The output shaft boss (h8) can be used to align the shaft.



#### ◇ Installing from the Rear Face



#### Note:

When installing the hollow-shaft flat gearhead from the rear face, provide dimension E to prevent the mounting plate from contacting the motor.

### ● Mounting Hole Dimensions

Unit=mm (inch)

Model	BLF230	BLF460	BLF5120
Nominal Bolt Size	M5	M6	M8
$\phi A$	70 (2.76)	94 (3.70)	104 (4.09)
$\phi B$ H8	$34 \begin{matrix} +0.039 \\ 0 \end{matrix}$ $\left( 1.34 \begin{matrix} +0.0015 \\ 0 \end{matrix} \right)$	$38 \begin{matrix} +0.039 \\ 0 \end{matrix}$ $\left( 1.50 \begin{matrix} +0.0015 \\ 0 \end{matrix} \right)$	$50 \begin{matrix} +0.039 \\ 0 \end{matrix}$ $\left( 1.97 \begin{matrix} +0.0015 \\ 0 \end{matrix} \right)$
$\phi C$	5.5 (0.22)	6.5 (0.26)	8.5 (0.33)
$\phi D$	25 (0.98)	30 (1.18)	35 (1.38)
E	29 (1.14)	39 (1.54)	44 (1.73)